

# Quick Setup Guide for MEC-5-DFL D5200 Iris Camera

## Contents of the Camera Carry Case – MEC-5-HCB D5200-N85



### Contents

1. Camera with macro lens
2. Direct Flash Illuminator
3. Camera Battery Charger
4. 18-55mm Zoom Lens
5. Lens rear cap/body cap
6. Camera Batteries
7. SDHC memory card (16GB)
8. USB Card Reader
9. Spare batteries (focus light), 3xAAA
10. Screwdriver for focus light battery pack
11. Camera USB cord
12. Camera A/V cord
13. Eyepiece cover (for use with LiveView)
14. Nikon User Manual
15. Carry Case



## Preparing the Iris Camera for Use – MEC-5-DFL-D5200-N85

1. Open Camera Carry Case and remove the camera with macro lens from the carry case and set down.



2. Lift Illuminator out of foam-padded case



3. Remove lens cap and turn the camera on. Mode dial is set to A=Aperture priority



4. Pop up the built-in flash by pressing button on left side



5. Place illuminator onto lens with battery pack at the 6:00 position (Flash is in the up position, Mode=A):





6. Rotate Illuminator 90 degrees, until it snaps into place with opening at 12:00 position:



7. Turn on focus light power switch by rotating control knob clockwise:



8. **Your camera is now ready to take iris photos.** When complete with the photography, reverse these steps to put the camera away.